

### OZONE TREATMENT FOR CARS, CARAVANS, BUSES, TRUCKS, YACHTS, BOATS...

1. Clean inside of the car and remove the source of odors.
  2. Place the Ozone Generator on the floor of the passenger seat or on the seat at the front of the car.
  3. Face the outlet of the device through the dashboard so the ozone molecules will be sucked into the air conditioning system which is behind the passenger glove compartment.
  4. Windows and doors should be closed, air conditioning set to the closed circuit, to the maximum cooling efficiency (the lowest temperature).
  5. Set the timer of the Ozone Generator to 10 minutes.
  6. Leave the car immediately and close the door.
  7. The time of treatment depends on the size of the car, the odor type, the degree of fungal coverage of air conditioning. They can prolong the treatment time.
- Repeat the previous steps if the unpleasant odor that you want to eliminate remains inside by setting the timer longer (10, 20, 30, 60, 120 minutes can be set).



OZONE GENERATOR 10G

After the treatment, turn-off the device and take it out of the car. After you open all the doors to allow the gas to dissipate, there will be a peculiar smell that can linger on for a few days. Wait at least half an hour with all doors wide open before entering the vehicle. The aroma of ozone, as we said, can remain for a few days, but the smell we wanted to attack, will have been eliminated, thanks to this process of environmental disinfection by ozone.

### SMELL THE FRESH AIR, NOT THE AIR FRESHENER.

#### HOW OZONE IS PRODUCED BY ELECTRICITY?

